



TIPS FOR BETTER MEASUREMENT PART 3

1. Use a “check standard” system to ensure your process is stable and operating within acceptable limits.
2. When performing hardness tests on items such as adjustable thread ring gages, be careful not take the tests in areas around the terminal holes what are drawn back after hardening.
3. Always create an uncertainty budget for each measurement procedure you employ to ensure you keep priorities right and take all factors into account. Similarly, ensure all staff realize that if they depart from the methods and equipment listed within the budget, it must be adjusted to reflect such changes.
4. When doing calculations, always be aware of what system should be used for rounding numbers.